

# Installation Instructions

## Type Pylon MIDI

by designer Troels Bøgely



Model: GVMMDT-10  
Material: glass reinforced plastic (GRP)  
Installation: vertical

### Installation of the uridan waterless urinal is very simple

If retrofitting existing flushing urinals with Uridan waterless urinals, please ensure that the sewer line is jetted and clean of uric scale before installation.

The uridan urinal must be fitted to a 50mm diameter sewer pipe and installed in accordance with AS/NZ3500.

1. Adjust the drainpipe.
2. Put the urinal at the right place, mark the holes on the floor and take the urinal away again.
3. Drill the holes for raw plugs, and insert the raw plugs.
4. Put the urinal back in place and fix screws.
5. Fill the waste trap (Pos. B) with water.
6. Insert the stainless steel cover (A).
7. Then pour 0.3 litres of uriLOCK over the cover. **Important!** Do not pour uriLOCK fluid before the stainless steel cover is inserted.
8. If required apply silicon sealant around the foot of the urinal.
9. The uridan urinal is now ready for use!

The PYLON urinal is designed to install directly over the floor waste using the bolts supplied.

Please leave customer care booklet, cleaning and maintenance instructions and suction device with customer.

