

## Uridan 'early model' urinals - Parts & Servicing

### Uridan Service Kits for pre 2018 urinals

All uridan urinals installed before July 2018 will have one of the uridan service kits shown below. The service kits form the water lock in the uridan urinals. These parts are required to ensure that the urinal meet the plumbing code.

Service Kit	Cover #	Pipe
<p><b><u>Service Kit 1:</u></b>  <b><u>Stainless Steel Cover #1 with Straight Pipe</u></b></p> <p>For fibreglass urinals only. <b>THIS STAINLESS STEEL COVER IS NO LONGER IN PRODUCTION.</b> Pipe is still available</p>		
<p><b><u>Service Kit 3:</u></b>  <b><u>Stainless Steel Cover #3 &amp; Straight Pipe (troughs only)</u></b></p> <p>For uridan CREW trough urinals only</p>		
<p><b><u>Service Kit 4:</u></b>  <b><u>Stainless Steel Cover #2/4 with Straight Pipe</u></b></p> <p>For uridan urinals with the fixed stainless steel rim in the urinal bowl. <b>THIS STAINLESS STEEL COVER IS NO LONGER IN PRODUCTION.</b> Pipe is still available</p>		
<p><b><u>Service Kit 5:</u></b>  <b><u>Stainless Steel Cover #5 with Straight Pipe</u></b></p> <p>Primarily for ceramic urinals</p>	 <p style="text-align: center;">or</p> 	
<p><b><u>Service Kit 6/7:</u></b>  <b><u>Stainless Steel Cover #6/7 with Flared Pipe incl. O-ring</u></b></p> <p>For ceramic and fibreglass urinals  The identifying feature O-ring on the pipe</p>		

Please look at the images carefully to determine which parts are required for your urinal.

## Identifying the service kit when you only have the urinal (and no spare parts)

If you DO NOT have your service kit at hand to compare to the images, you can determine which parts you require for your specific urinal as follows:

1. For early model uridan **trough urinals** (CREW) – you will require Service Kit 3 (diameter 109mm)
2. For early model, single bowl urinals check for:
  - a. If you have a fibreglass urinal requiring a larger than usual cover, you will require the **Service Kit 1** (this 97mm cover is no longer in production but the inner pipe remains available)
  - b. if the urinal has a fixed stainless-steel rim in the bowl – you will require the **Service Kit 4** (this 68mm cover is no longer in production, but the inner pipe remains available)
  - c. if the urinal's inner waste trap is round and you require a cover with a 77mm diameter – you will require the **Service Kit 5** with the straight pipe. You can identify the shape of the waste trap by taking the urinal off the wall; or, if the urinal is clean, you may be able to determine the shape of the inner waste trap by looking down into the urinal opening from the top.
  - d. If the urinal's inner waste trap is triangular, you will require the **Service Kit 6** with a 77mm cover and the flared pipe (and the O-ring on the pipe). You can identify the shape of the waste trap by taking the urinal off the wall; or, if the urinal is clean, you may be able to determine the shape of the inner waste trap by looking down into the urinal opening from the top.

The servicing procedure for urinals installed pre-2018 can be found below.

## Uridan servicing for urinals with Service kits (installed pre- July 2018)

### 1. Open

- » Insert the uridan® hook into the elongated cover opening and turn 90°.
- » Remove the cover by lifting upwards and then submerge it in a bucket full of water.



### 2. Clean

- » Pull out the angularly cut pipe with the aid of combination pliers. This allows the contents of the odour trap to flow into the drain.
- » Clean away the urine residue with the brush and then rinse away with water from the bucket.



### 3. Refill

- » Use the combination pliers to reinsert the angularly cut pipe until you feel a resistance. You will hear a "click" when the pipe locks into place.
- » Fill the odour trap with water until it flows back out over the top edge of the angularly cut pipe.



### 4. Close

- » Replace the cover.
- » Pour new urilock® blocking fluid directly over the cover.



## Consumables required to complete servicing

Product Code	Description	Comments
uriCLEAN 8 (Option 1)	uriCLEAN Cleaning Solution 8 x 500ml spray bottles	Anti-bacterial cleaning solution, specially formulated to be used with the uriLOCK urinal oil. uriCLEAN helps to retain the high gloss finish of your urinal bowls.
uriCLEAN 5 (Option 2)	uriCLEAN Cleaning Solution 1 x 5 litre bottle	Anti-bacterial cleaning solution, specially formulated to be used with the uriLOCK urinal oil. uriCLEAN helps to retain the high gloss finish of your urinal bowls.
uriLOCK 5 (Option 1)	uriLOCK blocking fluid 1 x 5 litre	long lasting urinal oil, environmentally friendly, slightly scented, biodegradable oil for waterless urinals. <b>5 litres services 17 urinals.</b>
uriLOCK 6 (Option 2)	uriLOCK blocking fluid 6 x 300ml bottles	long lasting urinal oil, environmentally friendly, slightly scented, biodegradable oil for waterless urinals. <b>1 x 6pack services 6 urinals</b>

If you require anything further, please don't hesitate to give us a call on 02 9986 2700.

All uridan products can be ordered through your plumbing wholesaler or directly through our [online store](#).